

Fig. 1

6658202




Fig. 2

09149443 09149443




Fig.3

FIRMWARE FLOW DIAGRAM MAIN SYSTEM OPERATION




Fig. 4

865060-8446460

COPY OPERATION DATA FROM MODULE TO MASS STORAGE




Fig. 5D

Fig. 5A

ERASE OPERATION ERASE DATA FROM MODULE




Fig. 5B

COMPUTER INTERFACE COMMAND UPLOAD / DOWNLOAD DATA, AND REMOTE CONTROL




Fig. 5C

00149443-000000